

Z 6019

# Z 6019: Power supply filter

for power supply systems 48 VDC




Figure 1: Block diagram and side view

#### Construction:

EMC interference suppressor filter:

The power supply filter Z 6019 dampens wide-banded, low energy switching interferences (burst) according to IEC EN 61000-4-4 up to 2 kV, and wide-banded, high energy switching overvoltages (surge) according to IEC EN 61000-4-5 up to 1 kV on a 48 VDC power supply circuit. The interferences are discharged to earth.

### Signalling:

The power supply filter contains a potential-free changeover contact to announce a power failure. Correct function is announced via a green LED.

#### Installation:

The power supply filter should be installed as near as possible to the 48 V feeding. With feeding lines > 0.5 m within the cabinet, the feeding line has to be screened:

- up to 35 A:  $2 \times 6 \text{ mm}^2$ , HIMA part no. 904 100001 up to 63 A:  $2 \times 16 \text{ mm}^2$ , HIMA part no. 904 100002

## Mounting:

The power supply filter is mounted with a locking hook on amounting rail. Thereby the contact to the housing earth is realized.

flat pin plug 6.3 x 0.8 mm Connection Construction printed circuit board, IP 00 **Dimensions** 40 x 20 x 88 mm (W x H x D) Operating voltage 48 VDC / -15 ... +20%

Loadability of the

relay contacts 1 A, 60 VDC Power consumption 8 mA at 48 VDC Ambient conditions -25 ... +70 °C