

F 6216A

(

F 6216A: 8-channel analog input module with transmitter supply

- · for transmitters in two-wire technique 4...20 mA
- Pt 100 inputs, current inputs 0/4...20 mA
- · with safety isolation to the plant and electrical isolation between the inputs
- · resolution: 12 bits
- · transmitter supply with safety isolation




Figure 1: Block diagram and front cable plug

Analog input module:

Input voltage 0...1.06 V (approx. 6 % overflow)

Digital values 0 mA = 0, 20 mA = 3840, 21.3 mA = 4095

R*: Shunt with 50 Ω ; 0.05 %; 0.125 W;

current input T<10 ppm/K; part-no: 00 0710500

 $\begin{array}{ll} \text{Input resistance} & \text{min. 1 M}\Omega \\ \text{Time const. input filter} & \text{approx. 2.2 ms} \end{array}$

Conversion time max. 4 ms for 8 channels

Basis error 0.2 % at 25 °C (of upper range value)
Operating error 0.4 % at 0...+60 °C (of upper range value)

Electric strength 200 V against Analog GND

 I_k for PT 100 2.5 mA Space requirement 8 SU

Operating data 5 VDC / 100 mA, 24 VDC / 590 mA

Transmitter supply:

Output short-circuit-proof
Output voltage 26 V...21 V (I > 1 mA)

 $\begin{array}{lll} \text{Output current} & & 0...25 \text{ mA} \\ \text{Load impedance} & & \text{max. } 900 \ \Omega \\ \text{Short circuit current} & & 30...40 \ \text{mA} \end{array}$

Channel	Connection	Color	Channel	Connection	Color	
IK for PT100	z2 z6	WHRD WHBK	IK for PT100	z2 z6	WHRD WHBK	
1	z4 x4 d10	BN WH	1	z4 x4 d10	BN WH	
2	z8 x8 z10	YE GN	2	z8 x8 z10	YE GN	Cable LiYCY 20 x 0.25 mm ² screened I = 750 mm q = 1 mm ² Flat pin plug 2.8 x 0.8 mm
3	z12 x12 d14	PK GY	3	z12 x12 d14	PK GY	
4	z16 x16 z14	RD BU	4	z16 x16 z14	RD BU	
5	z20 x20 d18	VT BK	5	z20 x20 d18	VT BK	
6	z24 x24 z18	WHGN WHBN	6	z24 x24 z18	WHGN WHBN	
7	z28 x28 d22	WHGY WHYE	7	z28 x28 d22	WHGY WHYE	
8	z32 x32 z22	WHBU WHPK	8	z32 x32 z22	WHBU WHPK	
L– L+	d26 d30	BK RD	L- L+	d26 d30	BK RD	
Cable screen		YEGN	Cable screen		YEGN	I = 120 mm q = 2.5 mm ²

Flat pin plug 6.3 x 0.8 mm, to be connected to the earth bar under the slot

Lead marking cable plug Z 7127 / 6216 / C.. / IT to connect current/voltage

Lead marking cable plug to connect smart transmitters
Z 7127 / 6216 / C.. / IT

Figure 2: Lead marking cable plug

Note to voltage inputs:

Note

It is recommended to short-circuit unused voltage inputs in the cable plug or on the appertaining terminal row.

Current inputs:

Measuring range 0/4 - 20 mA





Figure 3: Current inputs

Smart transmitter



R01, R03, R05, R07, R09, R11, R13, R15 = $50~\Omega$, 0.05 % R02, R04, R06, R08, R10, R12, R14, R16 = $220~\Omega$, 0.5 W, 5 %, Part no.: 00~0471221

Connection of smart transmitter

Figure 4: Connection of smart transmitter