


K 9202B

K 9202B Cabinet Fan

The K 9202B cabinet fan is a suction fan equipped with the following components:

- 2 axial fans
- Redundant supply
- Fan operation monitoring
- Voltage monitoring



Application: Ventilation of the control cabinet. Air is sucked out of the control cabinet.

Installation site: Below the cut-out on top of the control cabinet.

Accessory: Standard cabinet equipped with ventilation grilles and mounting material for cutout on top of the control cabinet.

Specifications:

Material Aluminum, anodized

Operating data 24 VDC, -15...+20 %, $r_{pp} \le 15$ %


max. 500 mA

Air flow 200 m³ per hour Rated speed 2800 min⁻¹

Sound pressure level approx. 50 dB(A)

Lifetime at 40 °C 62 500 h
Weight 1.2 kg
Ambient temperature -20...+70 °C

Block diagram:



The fault relais contacts can be used to connect optical and acoustic detectors with current input p to 1 A.


Operation and error indicators:

Operating state	Connector plug, pins 4 and 5	Connector plug, pins 5 and 6	LED Fail	LED 24 V
No fault	Open	Closed	OFF	ON
Operating voltage < 20.4 V or > 28.8 V	Open	Closed	OFF	BLINKING
Operating voltage is missing or fuse is defective	Closed	Open	OFF	OFF
Fan malfunction *	Closed	Open	ON	ON

^{*} Fan speed < 75...85 % of the rated speed

Connector plug:

The connector plug is used to connect the cabinet fan to the power supply. A redundant power supply can be connected to terminal 3. Optical and acoustic detectors can be connected to terminals 4...6.



The following wires can be connected:

Wire	Cross-section	Connection
Single-wire	0.082.5 mm ²	Spring-cage terminal *
Finely stranded	0.251.5 mm ²	Spring-cage terminal *
Finely stranded with wire end ferrule	0.252.5 mm²	Spring-cage terminal *

^{*} Actuation tool (screwdriver slotted 3.5 x 0.5 mm)